

OWNER'S MANUAL

Read and understand this entire manual before allowing child to use this product! For assistance contact Razor. DO NOT RETURN TO STORE.

NOTE: Manual illustrations are for demonstration purposes only. Illustrations may not reflect exact appearance of actual product. Specifications subject to change without notice.

Please have your product along with the 22 character product I.D. code with you before contacting Razor for warranty assistance and/or replacement parts.

Product I.D. Code:

CONTENTS

Safety Warnings	1
Before You Begin	
Assembly and Set-Up	
Pre-Ride Checklist	

SAFETY WARNINGS

WARNING: Riding the RipRider[®] 360° Caster Trike can be a hazardous activity. Certain conditions may cause the equipment to fail without fault of the manufacturer. The RipRider 360° Caster Trike can and is intended to move, and it is therefore possible to lose control, fall off and/or get into dangerous situations that no amount of care, instruction or expertise can eliminate. If such things occur you can be seriously injured or die, even when using safety equipment and other precautions. RIDE AT YOUR OWN RISK AND USE COMMON SENSE.

This manual contains many warnings and cautions concerning the consequences of failing to maintain, inspect or properly use your RipRider 360° Caster Trike. Because any incident can result in serious injury or even death, we do not repeat the warning of potential serious injury or death each time such a possibility is mentioned.

APPROPRIATE RIDER USE AND PARENTAL SUPERVISION

This manual contains important safety information. It is your responsibility to review this information and make sure that all riders understand all warnings, cautions, instructions and safety topics, and assure that young riders are able to safely and responsibly use this product. Razor recommends that you periodically review and reinforce the information in this manual with younger riders, and that you inspect and maintain your child's RipRider 360° Caster Trike to ensure their safety.

The recommended rider age of 5 and older for RipRider 360° Caster Trike is only an estimate, and can be affected by the rider's size, weight or skills. Any rider unable to fit comfortably on the RipRider 360° Caster Trike should not attempt to ride it. **A parent's decision to allow his or her child to ride this product should be based on the child's maturity, skill and ability to follow rules.**

Keep this product away from small children, and remember that this product is intended for use only by persons who are, at a minimum, completely comfortable and competent while operating the RipRider 360° Caster Trike.

DO NOT EXCEED THE WEIGHT LIMIT OF 160 LB (73 KG).

Rider weight does not necessarily mean a person's size is appropriate to fit or maintain control of the RipRider 360° Caster Trike.

ACCEPTABLE RIDING PRACTICES AND CONDITIONS

Always check and obey any local laws or regulations which may affect the locations where the RipRider 360° Caster Trike may be used on public property. The RipRider 360° Caster Trike is meant to be used only in controlled environments free of potential traffic hazards and not on public streets. Do not ride your RipRider 360° Caster Trike in any areas where pedestrian or vehicle traffic is present. Ride defensively. Watch out for potential obstacles that could force you to swerve suddenly or lose control. Be careful to avoid pedestrians, skaters, skateboards, scooters, bikes, children or animals who may enter your path, and respect the rights and property of others.

Maintain a hold on the handlebars at all times.

Never carry passengers or allow more than one person at a time to ride the RipRider 360° Caster Trike.

Never use near streets, swimming pools, hills, steps, or sloped driveways.

Never use headphones, a cell phone or text when riding.

Never hitch a ride with another vehicle.

The RipRider 360° Caster Trike is intended for use on solid, flat, clean and dry surfaces, such as pavement or level ground, without loose debris, such as rocks or gravel. Wet, slick or uneven and rough surfaces may impair traction and contribute to possible accidents. Do not ride the RipRider 360° Caster Trike in mud, ice, puddles or water. Avoid excessive speeds that can be associated with downhill rides. Never risk damaging surfaces, such as carpet or flooring, by use of a RipRider 360° Caster Trike indoors.

Do not ride at night or when visibility is impaired.

PROPER RIDING ATTIRE

Riders should always wear a properly fitted helmet that complies with U.S. Consumer Safety Commission (CPSC) Standard 16 CFR 1203. A helmet may be legally required by local law or regulation in your area. Elbow and kneepads, long sleeved shirt and long pants are recommended. Always wear closed toe shoes, and keep shoelaces tied and out of the way of the wheels. Never ride barefooted or in sandals.

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES RISK OF SERIOUS INJURY. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.

BEFORE YOU BEGIN

Remove contents from box and check parts against parts diagram found on page 6. Remove the separators that protect the components from damage during shipping. Inspect the contents of the box for scratches in the paint or dents that may have occurred during shipping. Because the RipRider 360° Caster Trike was partially assembled and packed at the factory there should not be any problems, even if the box has a few scars or dents.


Estimated Assembly and Set-Up Time

Allow up to 15-20 minutes for assembly.

WARNING: DO NOT USE NON-RAZOR PRODUCTS WITH YOUR RIPRIDER 360° CASTER TRIKE. The RipRider 360° Caster Trike has been built to certain Razor design specifications. The original equipment supplied at the time of sale was selected on the basis of its compatibility with the frame, fork and all other parts. Certain aftermarket products may not be compatible and will void your warranty.



- See locations to the left
- 1. Frame (underneath unit)
- Box side of UPC (not shown)



□ Required Tools

Two (2) 5 mm Allen wrenches




Plastic Bag Contents:

- Tools
- Owner's Manual

Need Help? Visit our web site for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at www.razor.com. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed at the back of this manual.


ASSEMBLY AND SET-UP

□ Attaching the Frame Required Tools: Two (2) 5 mm Allen wrenches



1 Using two (2) 5 mm Allen wrenches, remove the coupling bolt on the end of the frame and the coupling bolt in the middle of the frame. Remove and discard the plastic insert.

Note: The coupling bolt in the middle of the frame is shorter.



2 Insert the rear frame into the frame assembly.




3 Securely tighten the (longer) coupling bolt on the rear frame using two (2) 5 mm Allen wrenches.




4 Securely tighten the (shorter) coupling bolt in the middle of the frame using two (2) 5 mm Allen wrenches.

□ Attaching the Front Fork


Required Tools: 13 mm wrench and 5 mm Allen wrench



1 Remove the steering bolt and locknut from the frame assembly with a 13 mm wrench and a 5 mm Allen wrench.



2 Insert the front fork into the frame assembly.



3 Be sure to properly align the slot on the headtube with the pin on the front fork as shown.




4 Reinsert the steering bolt and secure with locknut using a 13 mm wrench and a 5 mm Allen wrench.

A WARNING: Failing to properly tighten the steering bolt that attaches the front fork assembly to the frame assembly can cause you to lose control and fall.


ASSEMBLY AND SET-UP

Attaching the Front Wheel


Required Tools: 5 mm Allen wrench and 10 mm wrench



1 Remove the four (4) coupling bolts from the front fork using a 5 mm Allen wrench and a 10 mm wrench.



2 Insert the wheel assembly into the front fork and align holes. When installing the wheel, make sure the letter **"F" and arrow** (located on the side of the wheel) are facing the direction as shown above.




3 Reinsert the coupling bolts through the front fork and tighten securely.

□ Attaching the Seat


Required Tools: Two (2) 5 mm Allen wrench



1 Using two (2) 5 mm Allen wrenches, remove the four (4) coupling bolts from the frame.



2 Align the four (4) holes in seat with the four (4) holes in frame. Insert the coupling bolts through the top and bottom of the frame.



3 Tighten the coupling bolts using two (2) 5 mm Allen wrenches.

Need Help? Visit our web site for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed at the back of this manual.

PRE-RIDE CHECKLIST



Wheels

Periodically inspect the wheels for excess wear.



Frame, Fork and Handlebars

Check for cracks or broken connections. Although broken frames are rare, it is possible for an aggressive rider to run into a curb or object and wreck and bend or break the frame. Get in the habit of inspecting your scooter on a regular basis.



Hardware/Loose Parts

Check and secure all fasteners before every ride. Make sure the steering bolt and casters are tight. There should not be any unusual rattles or sounds from loose parts or broken components. If the unit is damaged, do not ride. Reference "Safety Warnings" on page 1 of this manual.



Safety Gear

Always wear proper protective gear, such as an approved safety helmet. Elbow pads and kneepads are recommended. Always wear closed toe shoes (lace-up with rubber soles) and keep shoelaces tied and out of the way of the wheels. NEVER RIDE BAREFOOTED OR IN SANDALS.



Laws and Regulations

Always check and obey any local laws or regulations.

Be Careful!

This product is not for aggressive or trick riding. Avoid steep inclines and don't ride too fast — you can lose control and fall. Skateboard parks are not designed for young riders. Never ride in traffic or on the street and watch your surroundings for pedestrians, bikers, boarders and skaters.

Maintain a hold on the handlebars at all times.

REPAIR AND MAINTENANCE

Cleaning

Wipe with a damp cloth to remove dirt and dust. Do not use industrial cleaners or solvents, as they may damage the surfaces. Do not use alcohol, alcohol-based or ammonia-based cleaners, as they may damage or dissolve the plastic components or soften the decals or decal adhesive.

Wheels and Bearings

Under normal circumstances and conditions, Razor wheels and wheel bearings are maintenance free. Nonetheless, it is the responsibility of the owner or guardian to periodically inspect the wheels for wear and tear, the axle for proper tightness, bearings for side-to-side play, and for loose parts. When a wheel develops play, this is an indication of excess wear and replacement is necessary. Replace immediately with only genuine Razor wheels. Worn wheels/ bearings are considered normal wear-and-tear and are not covered by the Razor Warranty. Wheels other than genuine Razor wheels may not be compatible with your Razor scooter. The use of anything other than genuine Razor replacement parts may affect your safety and will void your warranty.

Replacement Parts

The most frequently requested replacement parts are available for purchase at some Razor retail partners. For the complete selection of replacement parts visit shop.razor.com.

Repair Centers


- For a list of authorized Razor repair centers:
- Check online at www.razor.com.
- Additional Customer Service contact information is listed at the back of this manual.

RIPRIDER 360° CASTERTRIKE PARTS

Keep your RipRider 360° Caster Trike rolling for years with genuine Razor parts. Visit our website to purchase replacement parts. (Specifications subject to change without notice.)

- 1. Handlebar Grip (x2)
- 2. Front Fork
 - 2-1. Front Fork Coupling Bolts (x4)
- 3. Front Cover
- 4. Steering Bolt
 - 4-1. Lock Nut
- 5. Front Wheel w/ Pedals and Cranks Complete

- 6. Rear Wheel Complete (x2)
 - 6-1. Rear Wheel Cover (Upper/Lower)
 - 6-2. Spring Washer
 - 6-3. Caster
 - 6-4. Axle Bolts
 - 6-5. Wheel
- 7. Seat
 - 7-1. Seat Coupling Bolts (x4)



Need Help? Visit our web site for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed at the back of this manual.

WARRANTY

Razor Limited Warranty

The manufacturer warranties this product to be free of manufacturing defects for a period of 6 months from date of purchase. This Limited Warranty does not cover normal wear and tear, or any damage, failure or loss caused by improper assembly, maintenance, or storage.

This Limited Warranty will be void if the product is ever:

- used in a manner other than for recreation or transportation;
- · modified in any way;
- rented.

The manufacturer is not liable for incidental or consequential loss or damage due directly or indirectly to the use of this product.

Razor does not offer an extended warranty. If you have purchased an extended warranty, it must be honored by the store at which it was purchased.

For your records, save your original sales receipt with this manual and write the serial number below.

CUSTOMER SERVICE CONTACT INFORMATION

Need Help? Visit our web site for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed below:

UNITED STATES

Razor USA LLC P.O. Box 3610 Cerritos, CA 90703 USA

+1 866 467 2967 Monday - Friday 8:00 AM - 5:00 PM Pacific Time

DISTRIBUTED IN THE UK BY:

Re:creation Limited 2 Meadows Business Park Station Approach, Blackwater Camberley, Surrey GU17 9AB United Kingdom

+44 (0) 118 973 6222 *Tel* +44 (0) 118 973 6220 *Fax* sales@recreationltd.co.uk

U.S. Patent No. D593,910 S

Printed in China for Razor USA LLC.

Copyright © 2003-2014 Razor USA, LLC. All rights reserved. RipRider[®], Razor[®] and the Razor logo design are among the registered trademarks of Razor USA LLC in the United States and/or select foreign countries.

EUROPE

Razor USA (Europe) Handelsweg 2 2742 RD Waddinxveen Netherlands

+44 (0) 120 267 2702

DISTRIBUTED IN AUSTRALIA BY:

Funtastic Limited Level 2, Tower 2, Chadstone Place 1341 Dandenong Road Chadstone VIC 3148 Australia

+1 800 244 543

ASIA

Razor USA (Asia) P.O. Box 3610 Cerritos, CA 90703 USA

+81 50 7579 6622 info@razor-asia.com